

Start delay adjustment to zero

ATTENTION!

First CAN actief in position adjustments.

By using transfer to:

KO: 011E

Put in OR:011E (read out)

Then OW:011E:0000000 (write)