

Can activering

OR:0031 lezen can bit

OW:0031:001001100 aanpassen CANbit

Start vertraging positioneren

OR:011E

OW:011e:00000000